

Door Station - Interior Quick Start Guide

For Your Information...

Things to Consider Before You Install this Device

- 1 Determine whether you want to use AC, DC power, or Power over Ethernet (PoE).
- 2 It's best to stand within 24" from the speaker when talking into the Control4® Door Station.
- 3 Make sure you've installed the Door Station Back Box before you install the Door Station.
- 4 Use the contacts and relays for non-secure devices only. For example, don't use it for a secured electronic gate.
- **5** If you plan to use WiFi:
- If you use an antenna for WiFi, ensure that the antenna's tip does not touch the Door Station's back box metal when threaded through the back box hole or any other metal surfaces.
- Check the WiFi signal strength after you wire the Door Station but before securing the device in the wall. You can do that at the driver's Properties page in Composer Pro.
- Make sure you've ordered an optional WiFi antenna.
- 6 Determine whether you want a backlit button for the Door Station. The button's backlight can be enabled or disabled in Composer Pro. You can also program the On/Off backlit button.

Things to Consider Before Adding this Device to a Composer Project

- 1 Make sure the WAP is on the same network as your controller and that the signal is strong.
- 2 Do you have an active Intercom license? You'll need to purchase one before you use this device.
- **3** Are there any other touch screens that will be communicating with this Door Station with audio and/or video capabilities?

Resources

Marketing, Installation, and Setup Guides

- 1 Door Station Interior Datasheet (PDF Dealer Products > Home Communication > Door Station page)
- 2 Door Station Interior Setup Guide (PDF Dealer Products > Home Communication > Door Station page)
- **3** READ THIS FIRST Notice for OS 2.3.0 (PDF, Dealer Software page)
- **4** OS 2.3.0 Release Notes (PDF, Dealer Software page)
- 5 Door Station Exterior Setup Guide (PDF, Dealer product Documentation page)
- 6 Door Station Back Box Installation Guide (PDF, Dealer Software > Documentation page)
- 7 Composer Pro Getting Started (PDF, Dealer Software > Documentation page) or Composer Pro Getting Started help (in the Composer Pro software)
- 8 Composer Pro User Guide (PDF in two parts, or online help on Dealer Software > Documentation page)

9 Touch Screens and Door Station - Exterior: A Comparison (PDF - Dealer Products > Home Communication > Touch Screens page)

How To's, Technical Notes, and Videos

We are constantly adding new quick reference sheets and videos to support our products. Please check our website often for new information.

- 1 Which Touch Screens Should You Use? (PDF Dealer Products > Home Communication > Touch Screens page)
- 2 Video Intercom Sessions over a Wireless Connection (PDF, Knowledgebase article #883)
- **3** System Performance Calculator (PDF, Knowledgebase article #747)

About This Document

Part number: 200-00318, Rev. A, 01/10/2013

